

**Product(s):** TP9000F,  
TP9001F, TP9002F, TP9003F,  
TP9004F, TP9005F, TP9006F,  
TP9007F

**Rev:** 21Aug12



## INSTRUCTIONS FOR INSTALLATION

### INCLUDED PARTS

- A. TP holder base assembly(1)
- B. TP holder bar (1)
- C. Mounting brackets (1)
- D. Screws (2)
- E. Wall anchors (2)
- F. Allen wrench (1)
- G. Set screw for bar - installed (1)
- H. Set screw for base - installed (1)



### MOUNTING INSTRUCTIONS ON DRYWALL

1. Determine the desired location for the TP holder.
2. Insert the TP holder bar (B) into the TP holder base assembly (A) at the desired angle, making sure there is enough room for a full paper roll, and tighten the set screw (G). Hold the assembly to the wall, and mark the position of the TP holder base.
3. Place the mounting bracket (C) on the wall (inside where you marked the TP holder base position) and mark the location of the two screw holes.
4. Drill 5/8" holes in the wall.
5. Place two of the screws (D) through one of the mounting brackets and attach wall anchors (E) to the screws. Push the wall anchors through the wall, and tighten the mounting bracket to the wall by tightening the screws. Pulling the mounting bracket away from the wall help secure the wall anchors while tightening the screws.
6. Attach the TP holder assembly to the installed mounting bracket, top first, and tighten the set screw (H), using the enclosed allen wrench (F). Be careful to not over-tighten the set screw.

**Note:** Although basic mounting hardware is included, be sure to use the proper mounting hardware for your wall type. If unsure, consult your local hardware store. Attaching the mounting brackets to wall studs or to backing made of 1x2 or 2x4 is the best method for mounting your new hardware.

### CARE

Clean only with a soft, dry cloth. To protect the finish, we do not recommend the use of polishes or abrasives. If you have any questions regarding your Vicenza product, please contact your local dealer.

