



Our products are designed for indoor use only unless otherwise stated. Products should be cleaned only with a soft, non-abrasive cloth dampened with clear water or a mild dishwashing liquid like Dawn™ and warm water. Please wipe dry with a soft, non-abrasive cloth. Do not use harsh cleaners or waxes to clean the product as these will erode the protective finish and void the warranty. Please do not leave water or soap residue on the product as chemicals or minerals contained within will eventually violate the protective coating and erode the finish.

K | TOP
KNOBBS